

Shooting Timer

The camera has two timers. With their help the user can program any time for forced shooting. Flexible settings allow you to set any days for shooting and the timers make it possible to take up to two forced shots per day.

If the camera is in active state when the timer triggers (triggered with the help of the sensor), the timer activation will be skipped. A picture taken with the help of the shooting timer is marked with a corresponding stamp at the bottom of the picture. For more information refer to photo stamps.

You can set the timers using the Mobile App and SMS commands. For more detailed information on the shooting timer settings please refer to the appropriate sections.

When to use the Shooting Timer

The Shooting Timer can be used for control shooting in case the [PIR sensor](#) does not function properly or when it is necessary to monitor the guarded object at a set time. In this case it is also possible to use [interval timer shooting](#). However, using interval timer shooting will reduce the battery life of the device by increasing the number of photos taken. It will also increase the amount of traffic consumed when using the GPRS network. Therefore, it is recommended that you use the Shooting Timer for control shooting.

From:

<https://doc.camkubik.com/> - **KUBIK KB**

Permanent link:

<https://doc.camkubik.com/en:functions:timers:sht>

Last update: **2021/02/09 10:44**