


PIR Sensor Settings



Using settings in this section, you can control the status of the [PIR sensor](#).

Status “On”

This option controls the general state of the PIR Sensor. If it is disabled, the camera will not respond to the PIR Sensor triggers. Disabling this option may be useful if you need to take photos at a preset interval ignoring movements.

Sensor Response Delay

This option sets a time interval during which the camera will not respond to the PIR Sensor triggers after it has been triggered and the image has been sent.

This option may be useful if false alarms occur or if the movement in the area is active and you want to increase the battery life of your camera.

Related articles

- [Automatic Update](#)
- [Device Settings](#)
- [Installation Coordinates](#)
- [PIR Sensor Settings](#)
- [Sending Settings](#)
- [Shooting Settings](#)
- [System Settings](#)
- [Time Synchronization](#)
- [Timer Settings](#)
- [Режимы SMS](#)

From:

<https://doc.camkubik.com/> - **KUBIK KB**

Permanent link:

<https://doc.camkubik.com/en:settings:mobile:settings:pir>

Last update: **2021/02/09 11:33**