

GPRS Settings



This feature is available only on camera models with 2G or 3G modems.

In this section you can configure [GPRS connection](#).

You can get the input data from your mobile operator.

Other sending settings

- [FTP Settings](#)
- [GPRS Settings](#)
- [MMS Settings](#)
- [SMTP Settings](#)
- [Yandex Disk Settings](#)

Related articles

- [Automatic Update](#)
- [Device Settings](#)
- [Installation Coordinates](#)
- [PIR Sensor Settings](#)
- [Sending Settings](#)
- [Shooting Settings](#)
- [System Settings](#)
- [Time Synchronization](#)
- [Timer Settings](#)
- [Режимы SMS](#)

From:

<https://doc.camkubik.com/> - **KUBIK KB**

Permanent link:

<https://doc.camkubik.com/en:settings:mobile:settings:sending:gprs>

Last update: **2021/02/09 11:52**