


Interval Timer



[Interval Timer](#) lets you set intervals at which your camera will take photos.

If no day of the week is selected, the timer will be disabled. .



Being activated this timer will disable all other timers.

From:

<https://doc.camkubik.com/> - **KUBIK KB**

Permanent link:

<https://doc.camkubik.com/en:settings:mobile:settings:timers:ptm>

Last update: **2021/02/09 11:48**